

N.B. For Max. Response on Short Waves, it is Important to have Trimmers A & B set Correctly. (A is set first, & B last.) The best Long & Short Wave Positions of A should Coincide. Do not Attempt alter Trimmers Unless Necessary.

