



Make sure the print is 100% Height is 115 mm

Cut out the window with a sharp knife using a straight edge and cutting board. The paper leaves a white edge in the window. Carefully black out the white edge from the back with a felt pen. The right image is a simple mask to cut out and glue behind so the red and gold are not back lit. Use PVA or glue stick to glue to the back of the dial scale. Laminate and cut out then fit into the cabinet. Alignment is difficult, a bit of electrical tape may help with temporary support.

The full article can be found in NZVRS Bulletin Vol 44 2023 Annual, pages 32-33.