




The Three Segments of each Switch Section are shown in BC. Position. Rotate 30° to Right for Medium Band and 60° to Right for SW. Band. When AC mains are used put chassis plug in "Vib" socket. When Vib unit used, insert Vib plug in Vib & leave chassis plug free.

AMENDMENTS

CKU
BKU

6 VALVE ALLWAVE AC-VIB. 1938 MODEL

RADIO (1936) LTD QUAY ST. AUCK.	
DRWN	G. J. Lamb.
CHCKD	R. J. O.
APPVD	R. J. O.
DATE	22/3/38

POWER → RED
CABLE → BLACK
WHITE