

K.C. 55 60 70 80 90 100 120 140 160 K.C.

BROADCAST

BAND 1

NEW ZEALAND
AUSTRALIA

BROADCAST
STATIONS

2YA 3YA 4YA 4YC 3YC 2XG 3ZB 2XM 1XH 4XD
2YC 1YA 4YZ 4YC 1XN 4ZB 2YD 2XA 2XN
6WA 3AR 2CO 2NR 2BL 3LO 2CY 2ZA 2KY 2NC 2MA
2CR 3WV 2FC

SHORTWAVE

BAND 2

SHORTWAVE

BAND 3

SHORTWAVE

BAND 4

TUNING

BAND SWITCH

HIGH FIDELITY

1 2 3 4 G

OFF ON

VOLUME

TOPE

11-5 11-7 12 13 M.C.
14-8 15 15-2 15-6 16 17 18 19 M.C.
19 METRES 25 METRES 31M 41M 49M